



MICROSWITCH BRACKET KIT
For Holley standard-flange carburetors without choke
CATALOG #72282
INSTALLATION INSTRUCTIONS

NOTE: *This bracket is not compatible with HP series carburetors and cannot be used on a carburetor that requires a choke.*

1. Mount switch to bracket so that the arm is pointed away from the bolt holes and insert screws through switch and bracket.
2. Thread nuts onto supplied screws, but verify switch arm alignment before snugging them down.
3. Mount the bracket using the fine threaded holes on the passenger side of the carburetor that would normally be reserved for an electric choke housing.
4. Check for full throttle, microswitch operation, and throttle return.

Catalog #72282
Rev. 3/08 - AJ/mc

IMPORTANT NOTE:

**Proper installation is the responsibility of the installer.
Improper installation will void warranty and may result in
poor performance and engine or vehicle damage.**



©2008 Edelbrock Corporation
Brochure #63-72282



MICROSWITCH BRACKET KIT
For Holley standard-flange carburetors without choke
CATALOG #72282
INSTALLATION INSTRUCTIONS

NOTE: *This bracket is not compatible with HP series carburetors and cannot be used on a carburetor that requires a choke.*

1. Mount switch to bracket so that the arm is pointed away from the bolt holes and insert screws through switch and bracket.
2. Thread nuts onto supplied screws, but verify switch arm alignment before snugging them down.
3. Mount the bracket using the fine threaded holes on the passenger side of the carburetor that would normally be reserved for an electric choke housing.
4. Check for full throttle, microswitch operation, and throttle return.

Catalog #72282
Rev. 3/08 - AJ/mc

IMPORTANT NOTE:

**Proper installation is the responsibility of the installer.
Improper installation will void warranty and may result in
poor performance and engine or vehicle damage.**



©2008 Edelbrock Corporation
Brochure #63-72282