



MICROSWITCH & BRACKET KIT
For WOT circuit activation
CATALOG #72279, 72280, 72281 & 72284
INSTALLATION INSTRUCTIONS

PLEASE study these instructions carefully before beginning this installation. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday.

IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation will void your warranty and may result in poor performance and engine or vehicle damage.

DESCRIPTION: Edelbrock Microswitch & Bracket Kits are an electrical safety precaution designed to prevent nitrous activation during part throttle operation.

1. Mount the switch on the bracket so that the switch arm is resting near the end of the throttle shaft.
2. Insert the supplied screws through the switch and bracket, then thread nuts onto the ends of the screws and snug to secure them.
3. Mount the bracket on the carb stud (*see chart*), then thread a nut onto the stud to secure the bracket and carburetor in place. An extended length stud may be required in some applications.

4. Check for full throttle, microswitch operation, and throttle return. The holes for mounting the switch have been slotted to allow for minor adjustments.

Part Number	Application	Stud Used For Mounting
72279	Universal	Varies
72280	Edelbrock Performer & Thunder AVS series AFB Carburetors	Rear, Passenger
72281	Holley 4500 flange 'Dominador' Carburetors	Front, Passenger
72284	Barry Grant Race Demon series Carburetors	Front, Passenger

Edelbrock Corporation • 2700 California St. • Torrance, CA 90503
Tech Line: (800) 416-8628

Catalog #72279, 72280, 72281, 72284
 Rev. 4/09 - AJ/mc

©2009 Edelbrock Corporation
 Brochure #63-72279



MICROSWITCH & BRACKET KIT
For WOT circuit activation
CATALOG #72279, 72280, 72281 & 72284
INSTALLATION INSTRUCTIONS

PLEASE study these instructions carefully before beginning this installation. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday.

IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation will void your warranty and may result in poor performance and engine or vehicle damage.

DESCRIPTION: Edelbrock Microswitch & Bracket Kits are an electrical safety precaution designed to prevent nitrous activation during part throttle operation.

1. Mount the switch on the bracket so that the switch arm is resting near the end of the throttle shaft.
2. Insert the supplied screws through the switch and bracket, then thread nuts onto the ends of the screws and snug to secure them.
3. Mount the bracket on the carb stud (*see chart*), then thread a nut onto the stud to secure the bracket and carburetor in place. An extended length stud may be required in some applications.

4. Check for full throttle, microswitch operation, and throttle return. The holes for mounting the switch have been slotted to allow for minor adjustments.

Part Number	Application	Stud Used For Mounting
72279	Universal	Varies
72280	Edelbrock Performer & Thunder AVS series AFB Carburetors	Rear, Passenger
72281	Holley 4500 flange 'Dominador' Carburetors	Front, Passenger
72284	Barry Grant Race Demon series Carburetors	Front, Passenger

Edelbrock Corporation • 2700 California St. • Torrance, CA 90503
Tech Line: (800) 416-8628

Catalog #72279, 72280, 72281, 72284
 Rev. 4/09 - AJ/mc

©2009 Edelbrock Corporation
 Brochure #63-72279